


## Steering Wheel Horn Switch Replacement



| Callout   | Component Name   |
|---|--|
| <p><b>Caution:</b> Refer to <a href="#">SIR Caution</a> in the Preface section.</p>   |  |
| <p><b>Preliminary Procedure</b></p> <p>Remove the inflatable restraint steering wheel module. Refer to <a href="#">Inflatable Restraint Steering Wheel Module Replacement</a> .</p> |  |
| 1   | <p>Horn Switch Bolt (Qty: 4)</p> <p><b>Notice:</b> Refer to <a href="#">Fastener Notice</a> in the Preface section.</p> <p><b>Tighten</b><br/>8 N·m (71 lb in)</p> |
| 2   | <p>Horn Switch</p> <p><b>Procedure</b></p> <p>Disconnect any electrical connectors as needed.</p>  |