

&lt;- Back

Forward -&gt;

**Document ID# 757261**  
**2003 Chevrolet Chevy Suburban - 4WD**

Print

## Scan Tool Output Controls

### Rear Wheel Steering Scan Tool Output Controls

Scan Tool Output Control	Additional Menu Selections	Description
2-Wheel Steer Mode Lamp	--	The scan tool commands the 2-Wheel Steer Mode Lamp ON when selected. The 2-Wheel Steer LED on the Rear Wheel Steering Mode Select switch should illuminate until commanded OFF.
4-Wheel Steer Mode Lamp	--	The scan tool commands the 4-Wheel Steer Mode Lamp ON when selected. The 4-Wheel Steer LED on the Rear Wheel Steering Mode Select switch should illuminate until commanded OFF.
4-Wheel Steer-Tow Mode Lamp	--	The scan tool commands the 4-Wheel Steer Tow Mode Lamp ON when selected. The TOW LED on the Rear Wheel Steering Mode Select switch should illuminate until commanded OFF.
Command 2-Wheel Steer	--	The scan tool commands the 2-Wheel Steering mode when ON is selected.
Command 4-Wheel Steer	--	The scan tool commands the 4-Wheel Steering mode when ON is selected.
Command 4 Wheel Steer-Tow	--	The scan tool commands the 4-Wheel Steering Trailering mode when ON is selected.
Command Rear Steer Left	--	The scan tool commands the Rear Steering Motor and turns the rear wheels left when commanded ON. The system returns to normal operation when the parameter is commanded OFF.
Command Rear Steer Right	--	The scan tool commands the Rear Steering Motor and turns the rear wheels right when commanded ON. The system returns to normal operation when the parameter is commanded OFF.
Learn Lateral Accelerometer	--	The scan tool performs the initialization of the Lateral Accelerometer when sensor is replaced.
Learn Alignment	--	The scan tool performs the Learn Alignment Procedure.
Steer Mode Lamps (All)	--	The scan tool commands all of the Rear Wheel Steering Mode Lamps ON when selected.

&lt;- Back

Forward -&gt;

**Document ID# 757261**  
**2003 Chevrolet Chevy Suburban - 4WD**

Print